

Unfolding the iSkibike Agility 1.5 - Page #2



#5 For shipping, the handle bar stem is rotated 180 degrees, lowered to a downward position, and the clamping screws retightened.

Loosen all three clamping screws at the fork, rotate the stem 180 degrees on the fork, realign the stem with the front ski binding adaptor, and retighten the clamping screws at the fork. Rotate the stem upward to a neutral or slightly raised position, retighten that clamping screw. Reinstall the handles bars in the stem in a comfortable riding position. Both the up and down rotation of the stem, and rotation of the handle bars in the stem can be adjusted for rider comfort and convenience.

#6 With the seat frame rotated steeply upward, place the seat post in position to go down into the seat tube, while threading the two front seat frame members: a) To either side of the main iSkibike frame; and b) Beneath/behind the round upward rotation blockers.



#7 Then insert the seat post into the seat tube, align an upper hole of the seat post with the one on the holes in the seat tube, and reinsert the seat pin. Once the seat pin is inserted on one side, USE JUST ONE HAND, with the fingers on one side of the seat pin depressing the button, place the thumb on the other side of the seat tube and squeeze the thumb and fingers together. The seat pin readily drops into place!



#8 For shipping, the screws for attaching the bottom of the springs that raise the seat up for loading and unloading ski lifts are installed in the correct hole on the iSkibike.

Remove these screws, and holding the back of the seat up, with the seat springs hanging down, reinstall the screws in the same hole each screw was just removed from. First insert the washer in the spring loop, and then insert the screw through the washer and spring loop simultaneously! These screws bottom out, be very careful not to over tighten them!